



TIE STRAPS LOOSELY
AROUND TRUNK

ARBOR TIE OR OTHER
WIDE, NON-ABRASIVE
BELT STRAPING

MULCH 3" DEPTH
TAPER TO 0" DEPTH
AT ROOT FLARE

BUILD MULCH SAUCER
AT EDGE OF PLANTING
HOLE

CUT AND REMOVE TOP
1/2 TO 2/3 OF BURLAP
AND WIRE BASKET

PLACE ROOT BALL
ON COMPACTED OR
UNDISTURBED SOIL

(2) 10' by 2" STAKES

PLANT TREE WITH
EXPOSED ROOT FLARE
1" ABOVE GRADE

BACKFILL WITH
PLANTING MIXTURE
(SEE SPEC.)

SCARIFY & ROUGHEN
PIT WALLS PRIOR TO
PLANTING

TREE PLANTING DETAIL

CITY OF CAMBRIDGE STANDARD SPECIFICATIONS AND DETAILS

SCALE: NTS

DATE OF ISSUE: 09/2013

SPEC. SECTION REF#: