


NOTES:

1. CLEAN ALL COLD PLANED SURFACES BEFORE APPLYING JOINT ADHESIVE, TACK COAT AND FINAL PAVEMENT.
2. APPLY TACK COAT TO COLD PLANED SURFACES PRIOR TO BEING OVERLAID AT THE RATE OF 0.10 GALLONS PER SQUARE YARD.
3. TEMPORARY PAVEMENT SHALL BE PLACED ALONG ANY LIP CREATED BY PAVEMENT REMOVAL. TEMPORARY PAVEMENT SHALL BE PLACED AT A SLOPE OF LESS THAN 1V:3H.

PAVEMENT TRANSITION

SCALE: N.T.S.

	PAVEMENT TRANSITION		
	CITY OF CAMBRIDGE STANDARD DETAILS		
	SCALE: N.T.S.	DATE OF ISSUE: 2/6	SPEC. SECTION REF#: